[ボウル、カップ] 材質: ポリプロピレン　耐熱温度: 60℃　容量: 300ml　食洗機使用可
[蓋] 材質: PCT樹脂　耐熱温度: 80℃　食洗機使用可
[パッキン] 材質: シリコーンゴム　耐熱温度: 100℃　食洗機使用可
BPAフリー　中国製

○電子レンジでご使用いただけません
○火のそばに置かないでください
○乳幼児の手の届く所には置かないでください
○ご使用後は汚れを早めに落とし、十分に乾燥させて保管してください
○洗浄の際はクレンザーやたわしを使用しないでください
○食洗機でのご使用に際しては製品に力が加わるような格納は避けて機器の上部に置いてください
○変形の原因となりますので煮沸はしないでください
○破損や水漏れの原因になりますので落としたり強い衝撃を与えないでください
○変形や破損の原因になりますので冷凍庫に入れて使用しないでください
○蓋の変形や、食品の腐敗の原因になりますので、食品は十分に冷ましてから蓋を閉めてください
○蓋を閉める際に溢れる可能性がございますので食品を入れすぎないようご注意ください
○蓋にシリコーンパッキンを装着してご使用ください
○蓋が確実に閉まっていることを確認してください
○完全密閉ではございませんので中身がこぼれないよう水平の状態でご使用ください
○水分が漏れる可能性がございますので、汁物など液体は入れないでください
○容器が蓋から落ち、破損の原因となりますので、持ち運ぶ際は蓋を持たないでください
○腐敗の原因になりますので、中身を入れた状態で長く放置しないでください
○車の中など高温になる所には放置しないでください
○柑橘類の皮に含まれるテルペンにより変質する場合がございますのでご注意ください
○匂いの強い食品や色素の濃い食品を長時間入れると、匂いや色素が落ちにくくなる場合がございますのでご注意ください
○表面に研磨跡が目立つ場合がございますが、製造時に生じる突起を削り滑らかに仕上げた跡です
○表面に細い線が目立つ場合がございますが、樹脂製品の成形時に生じるもので亀裂ではございません

Designed by KINTO Japan
株式会社キントー TEL 0120-34-7830
www.kinto.co.jp

2105

[Bowl, Cup] Material: Polypropylene　Upper tempereture torelance: 60°C/140°F
Capacity: 300ml/10.2oz　Dishwasher safe
[Lid] Material: Copolyester　Upper temperature torelance: 80°C/176°F　Dishwasher safe
[Sealing] Material: Silicone　Upper temperature torelance: 100°C/212°F　Dishwasher safe
BPA Free　Made in China

Do not use in a microwave.
Do not place near open flames. Keep out of reach of children.
Immediately wash and dry well after use, and keep dry when not in use.
Wash with care. Do not use abrasive cleansers or steel wool.
When using a dishwasher, please store them in the upper basket to avoid force and weight applied to them.
Do not put this product in boiling water as it may cause deformation.
Do not drop or subject the product to strong impact as it may cause breakage or leakage.
Do not put the product in a freezer as it may cause warp or breakage.
Make sure the food is cooled down enough before closing the lid to avoid deformation of the lid and food spoilage.
Be careful not to pour too much food as it may overflow when closing.
Attach the silicone ring to the lid.
Close the lid tightly to prevent spills or leakage when carrying.
Keep it horizontally as the container is not completely sealed.
Do not put liquids such as soup in this product as it may leak out.
Do not hold by the lid as the tumbler may fall and break.
Do not leave the beverage inside the product for long time as it may spoil.
Do not leave the product under high temperature such as in a car.
Please note that using the product with citrus fruit juices may cause the product to deteriorate due to terpene contained in the fruit's skin.
Keeping food with strong odor or color in this product for a long time may cause transfer of the the smell or the color.
Some products may have roughness on the surface due to the polishing process to remove sharp parts.
Some products may have thin lines on the surface due to plastic manufacturing process.

シリコーンパッキンの向きを正しく装着してご使用ください。
Please attach silicone ring in the correct direction.



